

DART AEROSPACE LTD		Work Order:	19070
Description: Repackage <del>K10002 Kit</del> 350 pod		Part Number:	K10002
Dwg:		Qty:	
		Page 1 of 2	

Step	Location	Procedure	By	Date	Qty
1	DC	Issue Traveller			
2	QC	Pull K10002 Kit B# 13235 From HAI display	JB	03.04.22	1
3	GA	Disassemble any assembled pieces	JB	03.04.22	1
4	QC	Inspect for damage	JB	03.04.22	1
5	FP	Touchup powder coat as per <del>Q</del> <del>Q</del> Repair scheme 1004	J	03.04.23	1
6	QC3	Inspect level 3	JB	03.04.23	1
7	ST	Replace missing pieces from Kit			
		4 x AN3-7A M5289			
		8 x AN3-15A M9599			
		1 x AN4-12A M12790			
		8 x AN4-13A M5786			
		4 x AN4-16A M9682	U	03.04.23	1
		24 x AN9603D10 M12790			
		26 x AN9603D416 M12749			
		12 x MS21042-3 M7690			
		13 x MS21042-4 M6339/M7690			
		1 x Document package			

Rev	Date	Change	Revised By	Approved
A		New issue		

[illegible]

Rev	Date	Change	Revised By	Approved
A		New issue		

DART AEROSPACE LTD	Work Order :	13235
Description: 350 Utility-Pod Accessories Kit	Part Number:	K10002
	Qty:	3

[illegible]

Rev	Date	Change	Revised By	Approved
A	99.01.06	New Issue	DM	
B	99.01.12	Changed pick list	DM	
C	00.06.26	Revised per ECN 296, new dwg K10002 rev. A	EC	

**REFERENCE ONLY**

172 00.06.27